

VW up!/Skoda Citigo/Seat Mii Mirror Cap Installation

Kit Contents

Qty – 2: Mirror Caps (Left and Right)

Tools Required

Mirror Glass Removal tool (optional)

Instructions

1. Angle the mirror glass as far downward and inwards as possible. Using your fingers, remove the glass from the mirror housing. Pull outwards on the top corner of the glass, as far inwards as you can get. **DO NOT PULL ON THE OUTER END OF THE MIRROR GLASS, AS YOU RISK BREAKAGE!** If unsure, there are plenty of video on YouTube explaining removal of VW wing mirror glass.
2. Locate the two tabs at the top of the inside of the mirror housing which retain the mirror cap. Press down and push in on the tabs while pulling the mirror cap backwards, to release (Fig. 2).
3. Install the new mirror cap. There are two small location clips on the side repeater/lower cover to engage (Fig. 3) whilst also locating the clips as shown in Fig. 2. These should pop into place as you push the cover on.
4. Re-position the mirror glass mount so that is centralised, both vertically and horizontally. This will aid clipping the mirror glass back onto its mount.
5. Repeat for the other side of the vehicle!

