

# VW up! Facelift Cold Air Inlet Grille Installation

## Kit Contents

- Qty – 1: Cold Air Inlet Grille Kit
- Qty – 1: Black Silicone Adhesive

## Tools Required

- Masking Tape
- Electric Drill with 4mm drill bit
- Dremel or similar cutting tool
- Side-cutters

## Instructions

1. Apply masking tape to the area where the grilles are to be installed (Fig. 1)
2. Locate the grille in the installed location (Fig. 2)
3. Mark the external profile of the open area of the grilles. (Fig.3)



4. Drill holes in the four corners of the profile area, then cut the profile area with a Dremel or similar tool. (Fig. 4)



5. The internal plastic panel will also require opening-up in a similar manner to allow airflow into the engine compartment.



6. Apply the black silicone to the rear of the grille according to the instructions on the tube. Recommendation is to leave the adhesive to cure for at least 1 hour before driving.



7. Repeat relevant steps according to the type of kit you have (2pcs, 3pcs, 6pcs)

**\*\*PLEASE NOTE – up!grade haus cannot be held responsible for any issues arising from incorrect installation of these parts\*\***