

## **SKU 44/45/53 SEAT AROSA VW LUPO / POLO 6N2**

Tools you will need:

- Combi Drill
  - 5mm-13mm HSS Drill Bits
  - 17mm and 19mm Spanner or Sockets
  - Hammer
  - Alan Key Set
  - Centre Punch
  - Stanley Knife (Optional)
  - Tape Measure
  - Marker Pen or Pencil
1. Rear Boot Floor Side Carpets
  2. Top Mounts Are OEM Mounting Points
  3. Align Your K-BRACE
  4. Mark Your Bottom Holes With A Permanent Marker
  5. Use a Centre Punch to pot the centres of each hole. Start by using a 5mm HSS Drill Bit and gradually work your way up to the required size, 13mm.
  6. Install the M10 Rivets using the tool provided.  
Video Link: [https://www.youtube.com/watch?v=3Og-tHIR\\_0I&feature=emb\\_title](https://www.youtube.com/watch?v=3Og-tHIR_0I&feature=emb_title)
  7. Align the K-Brace and use the M10 x 20 Bolts provided to fix it into place.
  8. Now All Aligned Fit K-Brace And Work Out Measurements On Where To Cut Trim  
Remove The Brace