



## SKU 09 Audi A3 8P Fitting Instructions

Tools you will need:

- Combi Drill
- 5mm-13mm HSS Drill Bits
- 17mm and 19mm Spanner or Sockets
- Hammer
- Centre Punch
- Stanley Knife (Optional)
- Tape Measure
- Marker Pen or Pencil

In your fitting kit you will have:

- M10 x 20 Hex Head Bolt (6)
- M10 x 19 Aluminium Rivet Nut (6)
- Rivet Nut Tool

1. Remove the rear seats from the car.
2. Remove all plastic trim and carpet from the boot space to expose the points of installation. Use the K-Brace to identify the fixing points, use a pen/pencil to mark the six holes.
3. Use a Centre Punch to pot the centres of each hole. Start by using a 5mm HSS Drill Bit and gradually work your way up to the required size, 13mm.

4. Install the M10 Rivets using the tool provided.

Video Link: [https://www.youtube.com/watch?v=3Og-tHIR\\_0I&feature=emb\\_title](https://www.youtube.com/watch?v=3Og-tHIR_0I&feature=emb_title)

5. Align the K-Brace and use the M10 x 20 Bolts provided to fix it into place.
6. Now that the K-Brace is in its final position, measure and cut the areas of carpet and trim that need to be removed.
7. Remove the K-Brace and install the carpet and trim ensuring your points of installation are adequately exposed.
8. Finally, refit the K-Brace.

Any questions or additional information about the installation of your K-Brace please do not hesitate to contact us through our website.

Thanks from everyone here at BAF Motorsport.