



SKU 15 Audi TT MK2 Fitting Instructions

Tools you will need:

- 5mm & 6mm Alan Keys
- Stanley Knife (Optional)
- Tape Measure
- Marker Pen

In your fitting kit you will have:

- M8 x 45 6mm Caphead Bolts (4)
- M8 Hex Head Flanged Nut (4)
- M8 x 15 Buttonhead Bolts (4)
-

PLEASE NOTE: ALL MOUNTING POINTS ARE OEM AND NO DRILLING IS REQUIRED TO INSTALL THIS K-BRACE.

1. Remove the rear seats from the car.
2. Remove all plastic trim and carpet from the boot space.
3. Use the brace to locate the four mounting points behind the rear seats.
4. Install the four brackets. Leave these slightly loose to help with the alignment of the K-Brace.
5. Fit the K-Brace, ensure the holes on the K-Brace are in line with holes on the brackets.
6. Once the alignment is set remove the brace and tighten the brackets.
7. Now that the brackets are fixed into position, measure and cut the areas of carpet and plastic trim that need to be removed.

8. Install the carpet, plastic trim and seats ensuring your brackets are adequately exposed.
9. Finally, refit the K-Brace.

Any questions or additional information about the installation of your K-Brace please do not hesitate to contact us through our website.

Thanks, from everyone here at BAF Motorsport.