



## SKU 08 BMW F20/F21 Fitting Instructions

Tools you will need:

- Stanley Knife (Optional)
- Tape Measure
- Marker Pen or Pencil
- 5mm & 6mm Alan Keys

In your fitting kit you will have:

- M8 x 40 Caphead Bolts
- M8 x 15 Buttonhead Bolts
- M8 Hex Head Flanged Nut

**PLEASE NOTE: ALL MOUNTING POINTS ARE OEM AND NO DRILLING IS REQUIRED TO INSTALL THIS K-BRACE.**

**THE TOP FIXING POINTS ON THIS BRACE ARE OEM, THE BOTTOM FIXING POINTS ARE USING THE THREADS FOR THE LUGGAGE HOLDERS.**

1. Remove the carpet and plastic side trim from the boot.
2. Remove the seat latch bolts and install the two brackets at the top leave these slightly loose.

**Please Note: The top two brackets must be angled back slightly and to ensure the rear seats can fully return.**

3. Put K-Brace into the car, line up all four mounting points. Ensure the holes on the top brackets are aligned with the holes on the K-Brace.
4. Remove the brace and tighten the top brackets.

5. Measure the areas of trim that need to be cut for the top brackets.
6. Install the carpet, plastic trim and seats ensuring your points of installation are adequately exposed.

**TIP: SLIDE THE TRIMMED CARPET OVER EACH SIDE OF THE BRACE.**

7. Finally, refit the K-Brace and trim any remaining carpet.

Any questions or additional information about the installation of your K-Brace please do not hesitate to contact us through our website.

Thanks, from everyone here at BAF Motorsport.