



SKU 82 C2 Fitting Instructions

Tools you will need:

- Combi Drill
- 5mm-13mm HSS Drill Bits
- 17mm and 19mm Spanner or Sockets
- Hammer
- Centre Punch
- Stanley Knife (Optional)
- Tape Measure
- Marker Pen or Pencil

In your fitting kit you will have:

- M10 x 20 Hex Head Bolt (2)
- M10 x 19 Aluminium Rivet Nut (2)
- Rivet Nut Tool
- M8x45 Cap Head Bolts (2)
- M8 Hex Nuts (2)
- M8x16 Button Head Bolt (2)

1. Remove all carpet from the boot space to expose the points of installation. Use the K-Brace to identify the fixing points, the top holes are the seat belt brackets replace the bolt is with a M10X16 Button head on each side to fit the brackets use a pen/pencil to mark the two lower holes.

2. Use a Centre Punch to pot the centres of each hole for the bottom fixings. Start by using a 5mm HSS Drill Bit and gradually work your way up to the required size, 13mm.

3. Install the M10 Rivets using the tool provided.
Video Link: https://www.youtube.com/watch?v=3Og-tHIR_0I&feature=emb_title

4. Align the K-Brace and use the M10 x 20 Bolts provided to fix it into place.

5. Now that the K-Brace is in its final position, measure and cut the areas of carpet and trim that need to be removed.

6. Remove the K-Brace and install the carpet and trim ensuring your points of installation are adequately exposed.

7. Finally, refit the K-Brace.

Any questions or additional information about the installation of your K-Brace please do not hesitate to contact us through our website.

Thanks from everyone here at BAF Motorsport.