



SKU 29 Ford Fiesta MK6 Fitting Instructions

Tools you will need:

- Combi Drill
- 5mm-13mm HSS Drill Bits
- 17mm & 19mm Spanners
- Hammer
- Centre Punch
- Stanley Knife (Optional)
- Tape Measure
- Marker Pen or Pencil

In your fitting kit you will have:

- M10 Rivet Nut (2)
- Rivet Tool
- M10 x 20 Hex Head Bolt (2)
- M8 x 45 Caphead Bolt (2)
- M8 x 15 Buttonhead Bolt (2)
- M8 Hex Flanged Nut (2)

1. Remove the carpet and plastic trim from either side of the boot space.

Remove the seats for additional access.

2. Locate the two torx bolts used for the seat belt mounts, these existing mounts are used to hold the top brackets in place. Once you have located these, install the brackets, then fit the K-Brace as to expose the lower mounting points of the K-Brace that require drilling.

3. Mark these holes with a pen/pencil. Use a Centre Punch to pot the centres of each hole. Start by using a 5mm HSS Drill Bit and gradually work your way up to the required size, 13mm.

4. Install the Rivet Nuts. Follow this video link for additional help on how to use the tool:

https://www.youtube.com/watch?v=3Og-tHIR_0I&feature=emb_title

5. Install the carpet and seats ensuring your brackets are adequately exposed

6. Finally, refit the K-Brace.

Any questions or additional information about the installation of your K-Brace please do not hesitate to contact us through our website.

Thanks, from everyone here at BAF Motorsport