



## SKU 17 Ford Fiesta MK7 Fitting Instructions

Tools you will need:

- Combi Drill
- 5mm-13mm HSS Drill Bits
- 17mm & 19mm Spanners
- Hammer
- Centre Punch
- Stanley Knife (Optional)
- Tape Measure
- Marker Pen or Pencil

In your fitting kit you will have:

- M10 x 20 Hex Head Bolt (4)
- M10 x 19 Aluminium Rivet Nut (4)
- Rivet Nut Tool

1. Remove the carpets and plastic trim from each side of the boot space. Next, remove the rear seats.

2. Apply the K-Brace to the OEM mounting points at the bottom. Use a pen/pencil to mark the top four mounting points.

3. Use a Centre Punch to pot the centres of each hole. Start by using a 5mm HSS Drill Bit and gradually work your way up to the required size, 13mm.

4. Install the M10 Rivets using the tool provided.

Video Link: [https://www.youtube.com/watch?v=3Og-tHIR\\_0I&feature=emb\\_title](https://www.youtube.com/watch?v=3Og-tHIR_0I&feature=emb_title)

5. Now take measurements of where the K-Brace sits so that the carpets and trim can be cut to fit around it.

6. Align the K-Brace and use the four M10 x 20 Hex Head Bolts provided to fix it into its final position.

Any questions or additional information about the installation of your K-Brace please do not hesitate to contact us through our website.

Thanks from everyone here at BAF Motorsport.