



SKU 40 HONDA CIVIC FN2 Fitting Instructions

Tools you will need:

- Combi Drill
- 5mm-13mm HSS Drill Bits
- 17mm and 19mm Spanner or Sockets
- Hammer
- Allen Key Set
- Centre Punch
- Stanley Knife (Optional)
- Tape Measure
- Marker Pen or Pencil

In your fitting kit you will have:

- M10 x 40 x 1.5 Washers (2)
- M10 Hex Head Bolt (2)
- M10 Rivet Nut (2)
- Rivet Tool

1. Remove the boot floor from the car, then remove the top covers for the shock absorbers.
2. Remove the shock absorber nuts, then place the upper mounting points of the K-Brace over the threads on both sides.
3. After, use a pen/pencil to mark the holes of the lower mounting points of the K-Brace.

4. Remove the K-Brace from the car.
5. Use a Centre Punch to pot the centres of each hole. Start by using a 5mm HSS Drill Bit and gradually work your way up to the required size, 13mm.
6. Install the M10 Rivets using the tool provided.
Video Link:
https://www.youtube.com/watch?v=3Og-tHIR_0I&feature=emb_title
7. Align the K-Brace and use the M10 x 20 Bolts provided to fix it into place.
8. Now the K-Brace is aligned measure and mark the areas of carpet and trim that need to be removed, then remove the K-Brace from the car.
9. Once the carpet has been adequately trimmed it can fit once again.
10. Finally, refit the K-Brace. Remember to fit the top mount covers, these may need a slight trim also.

Any questions or additional information about the installation of your K-Brace please do not hesitate to contact us through our website.

Thanks, from everyone here at BAF Motorsport.