



SKU 88 Nissan GTR Fitting Instructions

Tools you will need:

- Combi Drill
- 5mm-13mm HSS Drill Bits
- 17mm and 19mm Spanner or Sockets
- Hammer
- Centre Punch
- Stanley Knife (Optional)
- Tape Measure
- Marker Pen or Pencil

In your fitting kit you will have:

- M12 x 20 Hex Head Bolt (2)
- M12 Rivet Nut (2)
- M8 Rivet Nut (2)
- M8 Button Head (2)
- M8 X 45 CAPHEADS (2)

1. Remove the rear trim from the car.

2. The K-Brace's top mount points are OEM and these need to be widened by 1mm to 11mm holes. (M8 RIV NUTS TO GO IN THIS HOLE)
3. The bottom mounting points are existing under a black rubber bung.
4. Install the M8/M12 Rivets using the tool provided.
Video Link: https://www.youtube.com/watch?v=3Og-tHIR_0I&feature=emb_title
5. Install all carpets and trim where necessary and install the upper brackets.
6. Finally, refit the K-Brace.

Any questions or additional information about the installation of your K-Brace please do not hesitate to contact us through our website.

Thanks, from everyone here at BAF Motorsport.