



---

## SKU 32 Renault Clio MK3 Fitting Instructions

Tools you will need:

- Stanley Knife (Optional)
- Tape Measure
- Marker Pen

In your fitting kit you will have:

- N/A

**PLEASE NOTE: ALL MOUNTING POINTS ARE OEM AND NO DRILLING IS REQUIRED TO INSTALL THIS K-BRACE.**

1. Remove the carpet from the boot of the car.
2. Remove 'Isofix bar' this will be the mounting points for the lower section of the K-Brace.
3. The mounting points for the upper section of the K-Brace utilise the shock absorber struts. Remove the nuts that hold the shock absorber in place.
4. Insert the K-Brace and align the four mounting points in the car.
5. Use the OEM fixings to fasten the K-Brace in place.
6. Measure the areas of carpet that need to be trimmed.

7. Reinstall the carpet, trim and seats ensuring your points of installation are adequately exposed.
8. Finally, refit the K-Brace.

Any questions or additional information about the installation of your K-Brace please do not hesitate to contact us through our website.

Thanks, from everyone here at BAF Motorsport.