



SKU 42 Renault Megane MK3 Fitting Instructions

Tools you will need:

- Stanley Knife (Optional)
- Tape Measure
- Marker Pen or Pencil

In your fitting kit you will have:

- M8 x 45 Caphead Bolt (2)
- M8 x 15 Buttonhead Bolt (2)
- M8 Hex Flanged Nut (2)

PLEASE NOTE: ALL MOUNTING POINTS ARE OEM AND NO DRILLING IS REQUIRED TO INSTALL THIS K-BRACE.

1. Remove the carpets from the boot space of the vehicle.
2. Use the K-Brace to locate the OEM mounting points from the brackets.
3. Loosely install the brackets followed by the K-Brace, ensure the holes on the brackets are aligned with the holes on the K-Brace
4. Once alignment is complete tighten the brackets in place.
5. Measure and cut any carpet or trim, then place them on to the K-Brace and install them all together in the car.
6. Once this is complete adequately tighten the K-Brace into its final position.

Any questions or additional information about the installation of your K-Brace please do not hesitate to contact us through our website.

Thanks, from everyone here at BAF Motorsport.