



SKU 28 Renault Twingo Fitting Instructions

Tools you will need:

- Combi Drill
- 5mm-13mm HSS Drill Bits
- 17mm and 19mm Spanner or Sockets
- Hammer
- Centre Punch
- Stanley Knife (Optional)
- Tape Measure
- Marker Pen or Pencil

In your fitting kit you will have:

- M10 x 20 Hex Head Bolt (2)
- M10 x 19 Aluminium Rivet Nut (2)
- Rivet Nut Tool

PLEASE NOTE: TOP FIXINGS ARE OEM AND USE THE SHOCK ABSORBER STRUTS.

1. Remove the carpet and plastic side trims from the boot space.
2. Remove Shock Absorber Top Nuts.
3. Fit the K-Brace over the threads on the shock absorbers then use a pen/pencil to mark the holes for the bottom mounting points.
4. Use a centre punch to pot the centres of each hole. Start by using a 5mm HSS drill bit and gradually work your way up to the required size, 13mm.

5. Install the M10 Rivets using the tool provided.

Video Link: https://www.youtube.com/watch?v=3Og-tHIR_0I&feature=emb_title

6. Install the carpet, trim and seats ensuring your points of installation are adequately exposed.

7. Finally, refit the K-Brace.

Any questions or additional information about the installation of your K-Brace please do not hesitate to contact us through our website.

Thanks, from everyone here at BAF Motorsport.