



## SKU 73 Peugeot 207 Fitting Instructions

Tools you will need:

- Combi Drill
- 11 HSS Drill Bit
- Spanner/Sockets Set
- Stanley Knife (Optional)
- Tape Measure
- Marker Pen or Pencil

In your fitting kit you will have:

- M8 x 20 (2)
- M8x 19 Aluminium Rivet Nut (2)
- M8 Rivet Nut Tool

1. Remove all plastic trim and carpet from the boot space to expose the points of installation.
2. The upper point of installation is an existing hole above the seat latch that requires widening to 11mm to allow the installation of rivets.
3. Install the M8 Rivets using the tool provided.  
Video Link: [https://www.youtube.com/watch?v=3Og-tHIR\\_0I&feature=emb\\_title](https://www.youtube.com/watch?v=3Og-tHIR_0I&feature=emb_title)
4. Align the Brackets and use the M8 x 20 Bolts provided to fix it into place.
5. Remove the bungs from the bottom of the car this will expose the bottom fixing points.
6. Now that the K-Brace fixing are exposed and in place, fix the brace into its final position, measure and cut the areas trim that need to be removed.

7. Remove the K-Brace and install the carpet and trim ensuring your points of installation are adequately exposed.

8. Finally, refit the K-Brace.

Any questions or additional information about the installation of your K-Brace please do not hesitate to contact us through our website.

Thanks from everyone here at BAF Motorsport.