



SKU 74 Renault Clio MK4 Fitting Instructions

Tools you will need:

- Stanley Knife (Optional)
- Tape Measure
- Marker Pen

PLEASE NOTE: ALL MOUNTING POINTS ARE OEM AND NO DRILLING IS REQUIRED TO INSTALL THIS K-BRACE.

1. Remove the carpet from the boot of the car.
2. This K-Brace uses the lower OEM MOUNTS from the isofix bar.
3. The mounting points for the upper section of the K-Brace utilise the shock absorber struts. Remove the nuts that hold the shock absorber in place.
4. Insert the K-Brace and align the four mounting points in the car.
5. Use the OEM fixings to fasten the K-Brace in place.
6. Measure the areas of carpet that need to be trimmed.
7. Reinstall the carpet, trim and seats ensuring your points of installation are adequately exposed.
8. Finally, refit the K-Brace.

Any questions or additional information about the installation of your K-Brace please do not hesitate to contact us through our website. Thanks, from everyone here at BAF Motorsport.