



SKU 54 Abarth 595 Fitting Instructions

Tools you will need:

- Allen Key Set
- Stanley Knife
- Tape Measure
- Marker Pen/Pencil

In your fitting kit you will have:

- M8 x 45 Caphead (x2)
- M8 x 25 Buttonhead Bolt (x2)
- M8 Hex Flanged Nut (x2)

PLEASE NOTE: ALL MOUNTING POINTS ARE OEM AND NO DRILLING IS REQUIRED TO INSTALL THIS K-BRACE.

1. Remove the carpet on either side of the boot space behind the seats if required.
2. Use the K-Brace to locate the existing holes on either side of the boot space.
3. Fix the brackets into place using the M8 x 45 Buttonhead Bolts and M8 Hex Flange Nuts.
4. Insert the K-Brace and ensure all holes are aligned.

5. Use the M8 x 45 Caphead Bolts and M8 Hex Flanged Nuts to adequately tighten the K-Brace into position.
6. Bottom Fixings are OEM and sit under the seat brackets using the same bolts.
7. Remove the K-Brace if then measure and cut the plastics if required.
8. Refit the K-Brace followed by the carpet.

Any questions or additional information about the installation of your K-Brace please do not hesitate to contact us through our website.

Thanks, from everyone here at BAF Motorsport