



SKU 56 Hyundai I30N Fitting Instructions

Tools you will require:

- Combi Drill
- 5mm-13mm HSS Drill Bits
- 17mm and 19mm Spanner or Sockets
- Hammer
- Centre Punch
- Stanley Knife (Optional)
- Tape Measure
- Marker Pen or Pencil

Your fitting kit will contain:

- M10 Rivet Tool
- M10 x 20 (4)
- M10 Rivet (4)

1. Remove the rear seats from the car along with the boot floor.
2. Remove the OEM brace.

3. Remove the side carpets and the upper two plastics situated on either side of the boot space. These are held in place with 10mm bolts.
4. Once the carpet has been removed exposing the area you need to drill, use your K-Brace as a template. Line your K-Brace up ensuring that it is level, you will be able to identify the two existing holes that need drilling out to 13mm.
5. Unbolt the earth strap cables.
6. There is an existing hole above the earth straps that requires drilling. Start with an 11mm drill bit and work your way up to a 13mm.
7. Install the Riv Nuts using the tool supplied.

Video Here: https://www.youtube.com/watch?v=3Og-tHIR_0I&feature=emb_title

8. Put your K-Brace into position using the four M10 x 20 bolts supplied in your fitting kit.
9. Remove the K- Brace and refit the carpet and plastics.
(BOOT FOLDING FLOOR REQUIRES TO BE IN BEFORE FITTING K-BRACE)
10. Cut the carpet to your personal preference, we chose to over cut the carpet due to the earth straps being very tight with limited movement. It is difficult to relocate them when the carpet is in.

11. Once carpet has been cut exposing the rivets tighten your K-Brace adequately using the four M10 x 20 bolts supplied.

12. Refit existing Hyundai brace.

Any questions or additional information about the installation of your K-Brace please do not hesitate to contact us through our website.

Thanks, from everyone here at BAF Motorsport.