



SKU 60 Toyota Yaris V1 Fitting Instructions

Tools you will need:

- Combi Drill
- 5mm-13mm HSS Drill Bits
- 17mm and 19mm Spanner or Sockets
- Hammer
- Centre Punch
- Stanley Knife (Optional)
- Tape Measure
- Marker Pen or Pencil

In your fitting kit you will have:

- M10 x 20 Hex Head Bolt (2)
 - M10 Rivet Nut (2)
 - Rivet Tool
1. Top mounting points of the K-Brace use the OEM shock absorber struts. Remove the nuts and install the K-Brace.
 2. With the top mountings in place align and level the K-Brace. Mark the bottom fixing holes using a pen/pencil.
 3. Use a Centre Punch to pot the centres of each hole. Start by using a 5mm HSS Drill Bit and gradually work your way up to the required size, 13mm.
 4. Install the M10 Rivets using the tool provided. Video Link:
https://www.youtube.com/watch?v=3Og-tHIR 0I&feature=emb_title

5. Align the K-Brace and use the M10 x 20 Bolts provided to fix it into place.
6. Now all aligned work out the measurements on where to cut the carpet and trim, then remove the K-Brace.
7. Reinstall the carpets and trim ensuring there is adequate access to the mounting points.
8. Finally, refit the K-Brace.

Any questions or additional information about the installation of your K-Brace please do not hesitate to contact us through our website.

Thanks, from everyone here at BAF Motorsport.