



SKU 68 AUDI A5 Fitting Instructions

Tools you will need:

- Allen Key Set
- Stanley Knife (Optional)
- Tape Measure
- Marker Pen
- 13mm HSS Drill Bit
- Spanner/Socket Set

In your fitting kit you will have:

- M8 x 45 6mm Caphead Bolts (2)
- M8 Hex Head Flanged Nut (2)
- M8 x 15 Buttonhead Bolts (2)
- M8 Riv Nut Tool (1)
- M10 Riv Nut Tool (1)
- M10 Rivet (2)
- M10x20 Hex Bolt (2)
- M12x20 Bolt (2)

1. Remove all the side carpets and boot floor from the vehicle.
2. Once all carpets have all been removed this will expose all mounting points. For the full k-brace the side mounts or existing 11mm holes that just require the 2x m8 riv nuts to be installed and the bottom mounts are existing. The top mounts require drilling these are existing oval holes that need widening to 13mm.

3. **To Install The Riv Nuts Using The Tool Supplied Follow Video Here**
https://www.youtube.com/watch?v=3Og-tHIR_0I&feature=emb_title
4. Align the K-brace and make sure all is aligned.
5. Remove the K-Brace and refit all trim and carpets.
6. Cut carpet adequately.
7. Re-install your finished product.