



## SKU 76 Vauxhall Adam Fitting Instructions

Tools you will need:

- Allen Key Set
- Stanley Knife (Optional)
- Tape Measure
- Marker Pen
- 11mm HSS Drill Bit
- Spanner/Socket Set
- 40mm Hole Saw

In your fitting kit you will have:

- M8 x 45 Caphead Bolts (4)
- M8 Hex Head Flanged Nut (4)
- M8 x 15 Buttonhead Bolts (4)
- M8 Riv Nut Tool (1)

1. Remove all the side plastics and boot floor from the vehicle.
2. Once all plastics have all been removed this will expose all mounting points. These are 4 holes that need widening to 11mm to install the rivet nuts supplied.
3. **To Install The Riv Nuts Using The Tool Supplied Follow Video Here**  
[https://www.youtube.com/watch?v=3Og-tHIR\\_0I&feature=emb\\_title](https://www.youtube.com/watch?v=3Og-tHIR_0I&feature=emb_title)
4. Align the K-brace and make sure all is aligned.
5. Remove the K-Brace and refit all trim

6. Cut trim adequately (40mm Hole Saw Recommended)

7. Re-install your finished product.