



---

## SKU 94 Vauxhall Insignia Fitting Instructions

Tools you will need:

- ALAN KEY
- Riv Nut Tool Tools
- Drill etc
- Stanley Knife (Optional)
- Tape Measure
- Marker Pen

In your fitting kit you will have:

- INSIGNIA FITTING KIT

1. Remove all Carpet From The Boot

2. Bottom fixing is oem and no drilling is required, Top Bracket Requires A 11mm Hole To Be Drilled For m8 Riv Nut all 4 brackets mount up 1<sup>st</sup> use your brace to work out where these mount

Drill your 11mm Hole and Follow this video [https://www.youtube.com/watch?v=3Og-tHIR\\_OI&feature=emb\\_title](https://www.youtube.com/watch?v=3Og-tHIR_OI&feature=emb_title)

3. Install Brackets to Your Car (LEAVE THESE LOOSE)

4. Align the K-Brace Into The Brackets To Make Sure All Alignment is fine with the holes in your K-brace

5. If Alignment Is Fine Tighten Your Brackets To The Car.

6. Now that the K-Brackets Are In Position , measure and cut the areas of carpet and trim that need to be removed.
  
7. Install the carpet, trim and seats ensuring your points of installation are adequately exposed.
  
8. Finally, refit the K-Brace.

Any questions or additional information about the installation of your K-Brace please do not hesitate to contact us through our website.

Thanks from everyone here at BAF Motorsport.