



---

## SKU 31 Seat Ibiza 6J Fitting Instructions

Tools you will need:

- Combi Drill
- 5mm-13mm HSS Drill Bits
- 17mm and 19mm Spanner or Sockets
- Hammer
- Centre Punch
- Stanley Knife (Optional)
- Tape Measure
- Marker Pen or Pencil

In your fitting kit you will have:

- M10 x 20 Hex Head Bolt (4)
- M10 x 19 Aluminium Rivet Nut (4)
- Rivet Nut Tool

1. Remove the rubber stops for the rear seats and remove the boot false floor.
2. After removing the rubber stops, use a the drill to widen these holes to 13mm.
3. Align Your K-BRACE and use a pen/pencil to mark the holes at the bottom.
4. Use a centre punch to pot the centres of each hole. Start by using a 5mm HSS Drill Bit and gradually work your way up to the required size, 13mm.
5. Install the M10 Rivets using the tool provided.  
Video Link: [https://www.youtube.com/watch?v=3Og-tHIR\\_0I&feature=emb\\_title](https://www.youtube.com/watch?v=3Og-tHIR_0I&feature=emb_title)
6. Re-align the K-Brace and trim the boot floor to suit before reinstalling it.
7. Fit the K-Brace into its final position.

Any questions or additional information about the installation of your K-Brace please do not hesitate to contact us through our website.

Thanks, from everyone here at BAF Motorsport.