



SKU 47 Skoda Octavia MK1 VRS Fitting Instructions

Tools you will need:

- Combi Drill
- 5mm-13mm HSS Drill Bits
- 17mm and 19mm Spanner or Sockets
- Hammer
- Centre Punch
- Stanley Knife (Optional)
- Tape Measure
- Marker Pen or Pencil

In your fitting kit you will have:

- M10 x 20 Hex Head Bolt (6)
- M10 Rivet Nut (6)
- Rivet Nut Tool

1. Start by removing the rear seats from the car.
2. Remove all plastic trim and carpet from the boot space to expose the points of installation.
3. Use the K-Brace to identify the fixing points, use a pen/pencil to mark the six holes.

4. Use a Centre Punch to pot the centres of each hole. Start by using a 5mm HSS Drill Bit and gradually work your way up to the required size, 13mm.

5. Install the M10 Rivets using the tool provided.

Video Link: https://www.youtube.com/watch?v=3Og-tHIR_0I&feature=emb_title

6. Align the K-Brace and use the M10 x 20 Bolts provided to fix it into place.

7. Now that the K-Brace is in its final position, measure and cut the areas of carpet and trim that need to be removed.

8. Remove the K-Brace and install the carpet and trim ensuring your points of installation are adequately exposed.

9. Finally, refit the K-Brace.

Any questions or additional information about the installation of your K-Brace please do not hesitate to contact us through our website.

Thanks, from everyone here at BAF Motorsport.