



## SKU 64 Volkswagen Golf mk2 Fitting Instructions

Tools you will need:

- Combi Drill
- 5mm-11mm HSS Drill Bits
- Hammer
- Allen Key Set
- Centre Punch
- Stanley Knife (Optional)
- Tape Measure
- Marker Pen or Pencil

In your fitting kit you will have:

- M8 x 20 Button Head Bolt (2)
- M8 Rivet Nut (2)
- M10 x 40 x 25 Washers (2)
- M8x45 Caphead (2)
- M8 Hex Nuts (2)
- Rivet Tool m8

1. Remove rear boot floor and side carpets from the car.
2. Top mounting points of the K-Brace use the OEM shock absorber struts. Remove the nuts and install the K-Brace.
3. With the top mountings in place align and level the K-Brace. Mark the bottom fixing holes using a pen/pencil. This point is 90mm down from the indentation you can see on the inner arch.

4. Use a Centre Punch to pot the centres of each hole. Start by using a 5mm HSS Drill Bit and gradually work your way up to the required size, 11mm.
5. Install the M18 Rivets using the tool provided. Video Link:  
[https://www.youtube.com/watch?v=3Og-tHIR\\_0I&feature=emb\\_title](https://www.youtube.com/watch?v=3Og-tHIR_0I&feature=emb_title)
6. Align the K-Brace and use the Bolts provided to fix it into place.
7. Now all aligned work out the measurements on where to cut the carpet and trim, then remove the K-Brace.
8. Reinstall the carpets and trim ensuring there is adequate access to the mounting points.
9. Finally, refit the K-Brace.

Any questions or additional information about the installation of your K-Brace please do not hesitate to contact us through our website.

Thanks, from everyone here at BAF Motorsport.