



## **SKU 02 Volkswagen Golf MK4 R32 Fitting Instructions**

Tools you will need:

- Combi Drill
- 5mm-13mm HSS Drill Bits
- 17mm & 19mm Sockets and Spanners
- Hammer
- Centre Punch
- Stanley Knife (Optional)
- Tape Measure
- Marker Pen or Pencil

In your fitting kit you will have:

- M10 x 20 Hex Head Bolt (8)
- M10 x 19 Aluminium Rivet Nut (9)
- Rivet Nut Tool

1. Remove side carpets and plastic trim from the boot space. Remove the rear seats from the car to expose the mounting points.
2. Use the K-Brace as a guide to identify the eight mounting points.
3. Use a pen/pencil to mark the eight holes, then remove the K-Brace. Use a Centre Punch to pot the centres of each hole. Start by using a 5mm HSS Drill Bit and gradually work your way up to the required size, 13mm.
4. Install the M10 Rivets using the tool provided.  
Video Link: [https://www.youtube.com/watch?v=3Og-tHIR\\_0I&feature=emb\\_title](https://www.youtube.com/watch?v=3Og-tHIR_0I&feature=emb_title)
5. Align the K-Brace and use the M10 x 20 Bolts provided to fix it into place.

6. Now that the K-Brace is in its final position, measure and cut the areas of carpet and trim that need to be removed.
7. Remove the K-Brace and install the carpet and trim ensuring your points of installation are adequately exposed.
8. Finally, refit the K-Brace.

Any questions or additional information about the installation of your K-Brace please do not hesitate to contact us through our website.

Thanks, from everyone here at BAF Motorsport.