



---

## **SKU 48 Volkswagen Polo AW Fitting Instructions**

Tools you will need:

- Combi Drill
- 5mm-13mm HSS Drill Bits
- 17mm & 19mm Sockets and Spanners
- Hammer
- Centre Punch
- Stanley Knife (Optional)
- Tape Measure
- Marker Pen or Pencil

In your fitting kit you will have:

- M10 x 20 Hex Head Bolt (8)
- M10 x 19 Aluminium Rivet Nut (8)
- Rivet Nut Tool

1. Remove all carpet from the boot space including the raised boot floor and remove the rear seats.
2. Once the carpets have been removed hold your brace up to the exposed area and locate the eight points required to fix the K-Brace.
3. Use a pen/pencil to mark the eight holes, then remove the K-Brace. Use a Centre Punch to pot the centres of each hole. Start by using a 5mm HSS Drill Bit and gradually work your way up to the required size, 13mm.
4. Install the M10 Rivet Nuts, follow this link for additional help:

[https://www.youtube.com/watch?v=3Og-tHIR\\_0I&feature=emb\\_title](https://www.youtube.com/watch?v=3Og-tHIR_0I&feature=emb_title)

5. Now that the K-Brace is in position and M10 Rivet Nuts have been installed, measure and cut the areas of carpet and trim that need to be removed.
6. Install the carpet, trim and seats ensuring your points of installation are adequately exposed.
7. Finally, refit the K-Brace.

Any questions or additional information about the installation of your K-Brace please do not hesitate to contact us through our website.

Thanks, from everyone here at BAF Motorsport.