



## SKU 100 HONDA CIVIC FK2

Tools you will need:

- Combi Drill
- 5mm-13mm HSS Drill Bits
- 17mm and 19mm Spanner or Sockets
- Hammer
- Alan Key Set
- Centre Punch
- Stanley Knife (Optional)
- Tape Measure
- Marker Pen or Pencil

In your fitting kit you will have:

- FK2
1. Rear Boot Floor And Top Mount Covers
  2. Top Mounts Are OEM Mounting Points
  3. Align Your K-BRACE
  4. Mark Your Bottom Holes With A Permanent Marker
  5. Use a Centre Punch to pot the centres of each hole. Start by using a 5mm HSS Drill Bit and gradually work your way up to the required size, 13mm.
  6. Install the M10 Rivets using the tool provided.  
Video Link: [https://www.youtube.com/watch?v=3Og-tHIR\\_0I&feature=emb\\_title](https://www.youtube.com/watch?v=3Og-tHIR_0I&feature=emb_title)
  7. Align the K-Brace and use the M10 x 20 Bolts provided to fix it into place.
  8. Now All Aligned Fit K-Brace And Work Out Measurements On Where To Cut Trim  
Remove The Brace,

9. Refit Boot Floor After Trimmed

10. Finally, refit the K-Brace, And Place Top Mount Covers On Top, These Require Small Amount Of Trimming.

Any questions or additional information about the installation of your K-Brace please do not hesitate to contact us through our website.

Thanks from everyone here at BAF Motorsport.