



---

## **SKU 69 SKODA FABIA MK2 Fitting Instructions**

Tools you will need:

- Combi Drill
- 5mm-13mm HSS Drill Bits
- 17mm and 19mm Spanner or Sockets
- Hammer
- Centre Punch
- Stanley Knife (Optional)
- Tape Measure
- Marker Pen or Pencil

In your fitting kit you will have:

- M10 x 20 Hex Head Bolt (4)
- M10 x 19 Aluminium Rivet Nut (4)
- Rivet Nut Tool

1. Remove all side trims from the rear boot space.
2. Remove Boot False Floor.
3. Once the rear of the car has been stripped you will be able to align the K-Brace up on the plates underneath the seat hook latch.
4. Mark all 4 holes with a permanent marker.
5. Use a Centre Punch to pot the centres of each hole. Start by using a 5mm HSS Drill Bit and gradually work your way up to the required size, 13mm.
6. Install the M10 Rivets using the tool provided.

Video Link: [https://www.youtube.com/watch?v=3Og-tHIR\\_0I&feature=emb\\_title](https://www.youtube.com/watch?v=3Og-tHIR_0I&feature=emb_title)

7. Align the K-Brace and use the M10 x 20 Bolts provided to fix it into place.
8. Remove the K-Brace and install the boot floor and trim adequately if you want the boot floor to remain in
9. Finally, refit the K-Brace.

Any questions or additional information about the installation of your K-Brace please do not hesitate to contact us through our website.

Thanks from everyone here at BAF Motorsport.