

Central Basket LED Troffer Retrofit

INSTALLATION AND USERS' GUIDE

WARNING

- Risk of fire. Turn off power before installation.
- Risk of electronic shock. Install only by certified electrician with gloves.
- To be used in indoor dry and damp location only.
- If the luminaire exhibits undesirable operation (buzzing, flickering, not working etc.) immediately turn off power, remove luminaire and contact manufacturer.
- Do not mass installation before testing.



INSTRUCTION FOR RECESSED MOUNTING

1. Disconnect or turn off power before installation. See Step ①
2. Remove the old lens, fluorescent tubes and ballast (if necessary) from fixtures.
Place the retrofit label in side of the existing troffer housing See Step ②
3. Insert these brackets between the T grid and old fixture housing.
Fasten brackets to old fixture housing using self-drilling screw. See Step ③
4. Slide and lock the LED troffer retrofit into place on one end of each of the brackets. See Step ④
Screw the safety cables to the old fixture housing. See Step ⑤
5. Make the electrical connection to the fixture in accordance with local electrical code.
Make all necessary connections, observing proper voltage and polarity. See Step ⑥
6. Once finished with the electrical connection, swing LED troffer retrofit so it sits flush, then using the hooks on the opposite end of the brackets secure retrofit into place. See Step ⑦
7. Turn on power, the fixture will illuminate. See Step ⑧

