

confetti cake diy bath bomb



Want to turn bath time into a treat?! These funfetti bath bombs smells like freshly baked cupcakes with sweet cream frosting, while glittering sprinkles add fun and festive colors to make any bathtime a party! With an all-natural fragrance and solubilizer, this bath bomb is free of polysorbate, alcohol, and synthetic ingredients!

ready set prep.

Cover your workspace and gather all your materials. Check off the list below to make sure all your tools are clean and ready for making!

kit supplies from makesy

- 1x stainless steel bath bomb mold
- 1x 18 oz sodium bicarbonate (baking soda)
- 1x 9 oz citric acid
- 1x .25 oz cocoa butter – deodorized wafers
- 1x 0.25 oz cococlean natural surfactant blend
- 1x .2 oz vanilla cupcake + rainbow sprinkles fragrance
- 1x .05 oz psychedelic eco glitter
- 1x 1.7oz borosilicate glass beaker
- 1x disposable spatula
- 2x organza bag
- 2x round hang tags
- 2x product stickers

additional tools needed from your home

- a large bowl for mixing

ingredient highlights.



- The lipids in cocoa butter forms a protective barrier over skin to hold in moisture
- Cococlean helps to soften hair and hydrate skin



carcinogen-free.



phthalate-free.



cruelty-free.



toxin-free.



sulfate-free.

For more inspo and ideas for your next makesy diy kit project, search the rest of our amazing diy kits on our website at www.makesy.com

m _

happy making!

steps.

step one: Combine 18 oz of sodium bicarbonate, 9oz of citric acid. Mix with clean hands and break up any clumps.

step two: Melt your cocoa butter deodorized wafers in 1.7oz borosilicate glass beaker by microwaving for 30 seconds at a time until completely melted.

step three: Add your cococlean natural surfactant blend to your melted cocoa butter and mix completely with your provided spatula.

step four: Add your mixture to your powder base and mix by hand until clump free and all oils are evenly distributed.



Tip: If your mixture sticks to your hand, scrape back into the bowl and continue mixing.

step five: Add your psychedelic eco glitter to your powder base and mix by hand until evenly distributed.



This eco-friendly glitter is biodegradable and drain-friendly.

step six: Fill each side of your stainless steel bath bomb mold (use your hands to pack it in there) and smash the two sides of the mold together.

step seven: Allow your bath bomb to rest for 10-15 minutes.

step eight: Remove your bath bomb from the mold and repeat step four and five until your entire mixture is used.

directions for use.

Fill your tub with warm water, drop in the bath bomb and lie back to enjoy its lovely color and gorgeous fragrance.

ingredient listing.

Sodium Bicarbonate, Citric Acid, Sodium Coco-Sulfate, Coco-Glucoside, Cocamidopropyl Hydroxysultaine, Theobroma Cacao (Cocoa) Seed Butter, Fragrance.

storage.

Keep bath bombs fresh and dry in one of our bath bomb or product holders, a big glass jar or anything else that keeps them away from water.