

Cutout and Installation

Place the ARC-80 into an $\text{\O}80\text{mm}$ cutout.

For thin surfaces – Hand tighten the fixing collar



For thick surfaces – Turn fixing collar upside down and tighten by hand



Then use the installation tool provided to ensure a tight fit.



Use Installation
Fixing Tool for
tightening.

Dimensions

