

9-651-1033, and 9-307-1033

# 2003-2004 Ford Mustang SVT Cobra “Terminator” DW65c and DW300c Fuel Pump Installation Guide



## Table of Contents

Important Notes .....	<a href="#">Page 3</a>
Suggested Tools .....	<a href="#">Page 3</a>
Module Disassembly .....	<a href="#">Page 4</a>
Pump Install .....	<a href="#">Page 6</a>
Flushing and Priming .....	<a href="#">Page 8</a>

### Parts List:

- DW65c or DW300c (x2)
- Fuel Sock (x2)
- Pinch Style Hose Clamps (x4)
- 4" Long Convulated Fuel Tube (x2)

## 2003-2004 Ford Mustang SVT Cobra DW65c and DW300c Fuel Pump Installation Guide

PLEASE READ – this guide is intended to aid in the installation of our products. It is recommended that factory manuals or instructions are followed to remove the fuel pump assembly from the vehicle. Some instructions in this guide are generic. The factory manual should supersede any contradiction.

**NOTE:** The convoluted fuel tubes included in this kit are specially designed for the 03-04 Mustang Cobra, one end is slightly larger than the other. The smaller end is designed for the fuel pump, and the larger end is designed for the plastic Y-fitting.

The fuel pumps are specially modified for the factory Ford electrical connector as well. The factory pumps and connector have a notch and tab that aligns them.

Below is a picture of suggested tools that will make the installation process easier.




**2003-2004 Ford Mustang SVT Cobra DW65c and DW300c Fuel Pump Installation Guide**

1 – Remove the 9/32" screw that secures the pumps to the module with the band strap. Remove the band from the module, it is hooked in on the opposite side, slightly unbend the band then unhook the loop.




2 – Unplug the factory electrical connectors, it may be easier to use a small flat head screwdriver or a pick tool to depress the latch due to the crowded nature of the module.



**2003-2004 Ford Mustang SVT Cobra DW65c and DW300c Fuel Pump Installation Guide**

3 – Here you can see the special guide that is specific to the 2003-2004 Mustang Cobra, and the specialty modified notch in the DeatschWerks pump.



4 – Remove the factory convoluted tubes from the top of the Y-Fitting. This is typically done with a knife, take care not to damage the fitting under the tubing. Once loose remove the pumps from the module.



**2003-2004 Ford Mustang SVT Cobra DW65c and DW300c Fuel Pump Installation Guide**

5 – Separate the fuel socks and the rubber isolators from the factory pumps, you will be re-using the isolators but not the filter socks. Slide the filter socks onto the DeatschWerks pumps and attach the supplied white rectangle filter socks, secure them in place with the supplied star washers.




6 – The supplied convoluted fuel hose has different sized openings at each end. The smaller end is designed for the DeatschWerks fuel pump, slip it on and secure it with one of the supplied hose clamps, repeat this on both fuel pumps.




**2003-2004 Ford Mustang SVT Cobra DW65c and DW300c Fuel Pump Installation Guide**

7 – Install the larger end of the hoses onto the factory black plastic Y-Fitting and secure them with the remaining supplied hose clamps.



8 – Plug the factory connectors back into the pumps, due to the special notch that's been added to the DeatschWerks pumps the factory connectors plug directly into the new pumps. Re-install the factory band strap onto to the module, hook the end through the eyelet on the module and secure with the OEM 9/32" screw.



**2003-2004 Ford Mustang SVT Cobra DW65c and DW300c Fuel Pump Installation Guide**

- 9 – Reinstall the assembly into the fuel tank and attach a length of hose to the outlet of the pump assembly allowing it to drain into a fuel safe container and prime the fuel pump assembly
- 10 – Crank the engine for a period long enough to prime the pump assembly and evacuate the air introduced during the pump installation process
- 11 – Attach supply line to the outlet of the pump assembly



For additional technical support please contact us at: [TechSupport@Deatschwerks.com](mailto:TechSupport@Deatschwerks.com) or 405.233.3991