

KANDARA

# Squeezy Wax Instructions

## Stage 1

Weigh out your wax, fractionated coconut and fragrance oil. The ideal mix is 75% fractionated coconut to 25% wax. Soy wax is recommended to use rather than paraffin.

For our example we will be using 75g of fractionated coconut and 25g of wax. Then adding 10g of fragrance oil.

## Stage 2

If you are colouring your squeezy wax with any mica then add this to your fragrance oil and stir to mix it well.

Melt the wax to normal wax making temperature and warm the coconut oil.

Add the fragrance oil to the coconut and stir to mix.

## Stage 3

Steadily add the fractionated coconut and fragrance oil to the melted wax and stir to mix.

Keep stirring until well mixed.

## Stage 4

Leave to stand until mix is cooled enough to start thickening. Give another stir and then pour into squeezy bottles.