



Windfall Lumber

711 Tumwater Blvd SW, Suite D
Tumwater, WA 98501
windfalllumber.com

360-352-2250 p
360-352-8294 f



PANEL ACCLIMATION & INSTALL

Acclimation

All woods react to moisture in the environment by expanding when moisture is added and by shrinking or contracting when moisture is removed. Thus, it is extremely important to allow ample acclimation time in the environment in which the product will be installed. Windfall recommends at least 7 days of acclimation time, the more the better in dryer climates. Product should be properly stacked with wood sticks in between to allow for air flow around all side of the product.

The most important factor for moisture at installation is enough acclimation time in the same space where the product will be installed so the wood can come to a stasis with the conditions of the space.

Install

This wood product must be installed in a way that allows for expansion and contraction over time. The product must be fastened with a screw and washer going through an oversize hole in the mounting surface. Screws should not go more than 1/2" into the product, and should be pre-drilled. Allow for the wood to move using whatever installation method you choose (i.e., french cleats, fastened through face into studs, or biscuiting).

Finishes

Finished - This product has been finished with a low VOC waterborne topcoat. There are 2 coats on the face and 1 coat on the back to seal the panel. Do not apply harsh or toxic cleaners and applicants to this product.

Unfinished - This product has not been finished. If finishing, we recommend the use of a professional finishing company with knowledge of the application of waterborne finishes. When finishing, always make sure to apply a coat of finish on the back of the panel to seal the wood.

Windfall cannot be held responsible for products that are installed incorrectly or without proper acclimation.