# WILL THIS FIT MY UNIT?



# INSTRUCTIONS FOR DETERMINING PRODUCT COMPATABILITY ON COLEMAN



#### Remove air conditioning ceiling assembly.

Remove all components unit you have full access to the plenum area.



### Measure the plenum depth

With Mounting Bracket attached . 5 1/8 Plus or minus 1/8
Without mounting bracket attached – 5 5/8 Plus or minus 1/8



## Verify the plenum width.

Standard 14" (13-3/4" minimum requirement).



#### Check ducting dimensions.

Ducting size—should measure 1-1/2" x 7-1/2" for optimal performance.



**Vertical location of the ductwork** 

(From bottom of AC to top of ducting)

With Mounting Bracket attached 2 3/8 Plus or minus 1/8

Without Mounting Bracket attached 2 5/8 Plus or minus 1/8