
WILL THIS FIT MY UNIT?



INSTRUCTIONS FOR DETERMINING PRODUCT COMPATABILITY ON DOMETIC





Remove all components unit you have full access to the plenum area.



Measure the plenum depth. With Mounting Bracket attached . 5 3/8 Plus or minus 1/8 Without mounting bracket attached – 5 5/8 Plus or minus 1/8

Verify the plenum width.

Standard 14" (13-3/4" minimum requirement).

Check ducting dimensions.

Ducting size—should measure 1-1/2" x 7-1/2" for optimal performance.

Vertical location of the ductwork (From bottom of AC to top of ducting) With Mounting Bracket attached 2 3/8 Plus or minus 1/8 Without Mounting Bracket attached 2 5/8 Plus or minus 1/8





If your measurements do not match the above requirements for stock compatibility, please see link below for fitment instructions.