

T3 Technique HD Endlink Installation Instructions



The new HD endlinks are a simple bolt-on to the T3 Technique anti-roll bar and the lower control arm. There are no "standard" washers on the bottom stud, only the black stepped "washer" and the serrated flanged nut. The small side of the stepped washer on the bottom joint points downward (see photo) to help center the stud in the hole. The yellow triangle-shaped tab is simply to help prevent the lower studs from spinning and can be oriented in any direction.

NOTE - For the upper joint stud, the caption in the above photo, "no washers under the nuts", is incorrect. The newest design calls for washers on the upper joint side as well as under the nuts. It is suggested that you use blue thread locker on all of the studs and torque each nut to 65 ft lb. If you have any questions about the installation, please send an email to contact@t3technique.com



©2019 T3 Technique LLC. All Rights Reserved