

T3 Technique HD Endlink Installation Instructions

The new HD endlinks are a simple bolt-on to the T3 Technique anti-roll bar and the lower control arm. There are no “standard” washers on the bottom stud, only the **black stepped “washer”** and the serrated flanged nut. The small side of the stepped washer on the bottom joint points downward to help center the stud in the hole. The triangle-shaped tab is simply to help prevent the lower studs from spinning and can be oriented in any direction. ***NOTE – You may need to hold onto the tab with vice grips, channel locks, etc. while tightening the bottom nut.** It is suggested that you use orange or blue (not red) thread locker on all of the studs and torque each nut to 65 ft lb. If you have any questions about the installation, please send an email to contact@t3technique.com

Note#1: Place black stepped washer onto the lower with the small side facing down, then insert the stud through the hole in the suspension. Add thread locker, install nut, and torque to 65 ft lb.

Note #2: Place one washer on the stud, insert stud through the bar, place the other washer onto the stud, add thread locker, install the nut, and torque to 65 ft lb.

