

BLOXRACING

INSTALLATION GUIDE

PN: BXIM-51000

BLOX Racing TGV Delete Kit



APPLICATIONS

2015+ SUBARU WRX
2014+ SUBARU FORESTER XT

INCLUDED

(2) TGV Delete Plates

PRODUCT DISCLAIMER

Some products may not be legal for use on public highways. It is the purchaser's responsibility to check and comply with all local, state and federal laws before installing components and operating vehicle. The installation and the use of some BLOX Racing performance products may also affect or void a vehicle's manufacturer warranty and insurance policy. BLOX Racing assumes no responsibility for any damage or injury to persons or property resulting in improper installations or misuse of any product and will not be responsible for any claims of loss of profit, labor and delay, indirect, incidental or consequential damages that might be claimed as a result of failure of any part. BLOX Racing reserves the right, without notice, to make changes in materials, specifications, product design, part numbers, packaging and labeling without incurring any obligation to the buyer for the previously purchased merchandise.

IMPORTANT NOTES

Installation of this product requires removing bolts from the upper portion of the intake manifold to access the OEM TGV. Installation of this part, using methods described below, requires the use of a pry bar. This allows the installation to take less than an hour of time. If a pry bar is not available, expect installation to take 2-3 hours and the removal of many more parts than described below. This part may require professional ECU re-calibration to function properly.






1. Remove the intercooler cover (upper two circles)
2. Remove the wire harness clip (lower right circle) and (2) 12mm bolts that secure the bracket. Remove bracket and set aside.
3. Remove (4) 12mm bolts on the left side of the upper intake manifold.
4. Unplug the TGV motor plug.



5. Repeat processes #3 and #4 to remove the bolts from the right side of the upper intake manifold.
6. Carefully pry the upper intake manifold up in order to remove the OEM TGV and to install your new BLOX Racing TGV delete kit.
7. Once the OEM TGV is removed, slide in each BLOX Racing TGV delete plate.
8. Reinstall the right and left side bolts back into the upper intake manifold. **18-20ft-lbs**
9. Reinstall the bracket.
10. Use electrical tape to cover the open end of the TGV motor plug.
11. Reinstall intercooler cover.

NOTE: After installation, it might be necessary to reset the ECU and/or have it recalibrated.

   **BLOXRACING** | 510-440-1605 | BLOXRACING.COM

12212 6TH St. • Rancho Cucamonga • CA • 91730