

decco
The Wow Surface

MicroTop One Floor System

Craftsman Approved

INSTALLATION GUIDELINES





MicroTop One Floors System Supplies:

1 – decco Primer

(Concentrated/Must be diluted 1:1 with water)

1 – decco Basecoat

1 – decco MicroTop One

(Finish Coats)

1 – decco Color Toner

1 – decco Ultra Seal Polyurethane

(matte or gloss finish)

2 - 6 to 8 quarts of water per pail

5 Gallon mixing pail

Variable speed mixer with paddle

Shoe-in spiked shoes

Black Series Stainless Steel Trowel

Black Series Concrete Smoother *(optional)*

decco Basecoat **Mixing** Process:

Step 1

Approximately 6 - 7 quarts of water in 5 gallon mixing pail

Step 2

Put in one pail of decco Basecoat powder

Step 3

Mix with paddle mixer until lump free

Step 4

Let “false set” for 2 minutes

Step 5

Remix, adding small amount of water if needed



decco Basecoat Application Process:

Step 1

Open cracks to be filled with Crack Repair Material

Step 2

Sand or Grind Floor with recommended Cup Wheels or Sand Paper/Sanding Screens

Step 3

Patch Floor if needed and let dry
(Must grind flush with floor after cured)

Step 4

Clean Floor with Floor Machine and Cleaning

Step 5

Fill cracks with Crack Repair Material and let dry

*NOTE *** SUB-FLOORS: The wood subfloor must either be solid hardwood flooring, a minimum of 3/4" tongue-and-groove, APA – rated, Type 1, exterior exposure plywood, or OSB equivalent. The subfloor should be solid and fixed securely to provide a rigid base. Any boards exhibiting movement should be re-nailed. The surface of the wood must be clean and free of oil, grease, wax, dirt, varnish, shellac, or any contaminant that might act as a bond breaker. Use Fiberglass Mesh plus decco Flex Membrane*

Step 6

Roll decco Primer and let dry.
Usually takes 15min ~ 30 min to get dry.

Step 7

Pour decco Basecoat mixture on dry primer.

Step 8

Use the DF Black Series Trowel, or alternatively decco Concrete Smoother and/or Magic trowel for smooth basecoat.
THIN TO WIN

Step 9

Sand the cured Basecoat with 120 grip Sandpaper/Sanding screen for smoother finish. This is critical as it can show thru finish coat if not smooth.

Step 10

Repeat Steps 8 & 9 if applicable (ONLY in case tiled floors OR SUB-FLOORS / if the grout is still visible)

Step 11

Completely sweep and vacuum up dust if sanding was done

decco MicroTop One Mixing Process:

Step 1

Add 1 bottle of decco Color Toner (INTEGRAL COLOR) into water in order to get approximately 6 - 8 quarts of water in 5 gallon mixing pail

Step 2

Put in one bucket of decco MicroTop One powder

Step 3

Mix with paddle mixer until lump free

Step 4

Let “false set” for 2 minutes

Step 5

Remix, adding small amount of water if needed



decco MicroTop One Finish Coates Application Process:

Step 1

Sand the cured Basecoat with 120 grip Sandpaper/Sanding screen for smoother finish

Step 2

Completely sweep and vacuum up dust if Sanding was done

Step 3

Roll decco Primer – diluted 1:1 with water on decco Basecoat surface and let dry.

Step 4

Apply decco MicroTop One on dry primer. If necessary, mist water on dry primer to give more working time. Use the Black Series Stainless Steel Trowel at a 45-degree angle and/or decco Concrete Smoother for smooth finish coat. It is important to trowel thin but not heavy pressure that could create heavy black burnish marks unless this is requested by customer. THIN TO WIN.

Step 5

Let dry and sand the cured Finish coat with 320 grit Sanding screens for smoother finish.

Step 6

Repeat Step 3, 4 & 5 for finish coat (2nd coat is mandatory in order to achieve the final look).

Step 7

Completely sweep and vacuum up dust if Sanding was done.



Sealing the Masterpiece

decco Ultra Seal Polyurethane Application Process:

Step 1

Mix decco Ultra Seal WB Two-component Polyurethane Sealer @ 10:1 ratio.

Step 2

Roll 1st coat of decco Ultra Seal WB Polyurethane and let cure for about 6 hours. Use a THIN TO WIN.

Step 3

Roll 2nd coat of decco Ultra Seal WB Polyurethane and let cure for Light Traffic (6 hours) & High Traffic (24 hours). THIN TO WIN.

Step 4

Apply decco Wax for long term maintenance (2 to 3 coats is recommended).

NOTE : Ultra Seal WB Polyurethane Sealer is best applied with a high-quality, 1/4-inch short nap roller. Microfiber applicator pad, or T-bar applicator, followed by a spiked roller



say hey!

decco Miami

ADDRESS

8217-19 NW 66th St,
Miami, FL 33166

PHONE

+1 (786) 282-4097

E-MAIL

info@heydecco.com

SOCIAL

@heydecco
www.heydecco.com

decco New York

ADDRESS

243 Grandview Avenue
Staten Island, NY 10303

PHONE

+1 (347) 801-2855

E-MAIL

sales@dfstudio.nyc

SOCIAL

@decconewyork

