

decco

live sample kit

Includes

- MicroTop One 100% Waterproofing Microcement 40lbs bucket x1
- Color toners 2oz. The 10 most popular colors of your choice:

White · Vision · Pearl Grey · Dark Grey · Black ·
Portland · Cement · Paris Stone · Champagne · Cocoa

Mixing Process:

1. Add 1 bottle of decco Color Toner 2oz (INTEGRAL COLOR) into water in order to get approximately 18 ~ 20 oz of liquid in 2-gallon mixing pail
2. Extract 4lbs of MicroTop One from the pail and blend it carefully with the liquid
3. Keep mixing with paddle mixer until lump free
4. Let "false set" for 5 minutes
5. Remix, adding small amount of water if needed

Application

1. Apply Decco Microtop ONE on your sample board (MDF panels are highly recommended). If necessary, mist water on dry primer to give more working time. Use the Black Series Stainless Steel Trowel at a 45-degree angle and/or Magic trowel for smooth finish coat. It is important to trowel thin but not heavy pressure that could create heavy black burnish marks unless this is requested by customer.
2. Let dry and sand the cured Finish coat with 320 grit Sanding screens for smoother finish
3. Repeat Step 1 & 2 for finish coat (2nd coat is mandatory in order to achieve the final look)
4. Completely sweep and vacuum up dust if Sanding was done
5. Seal using our proprietary sealers: Ultra Seal, Eco Seal and/or Epoxy Seal

Clean Up:

Clean skin with soap and water. Tools and equipment should be cleaned with Xylene or Lacquer thinner. Consult MSDS for safety and health precautions.
40 sq.ft. per color @ two- coats



decco - Miami
8217-19 NW 66th Street
Miami, FL 33166
Tel: +1 (786) 282-4097
info@heydecco.com

decco - New York
243 Grandview Ave
Staten Island, NY 10303
Tel: +1 (347) 801-2855
sales@dfstudio.nyc

www.heydecco.com
Follow us! @heydecco