

# SmallDogPrints Light Kit Assembly



FIG. 1



FIG. 2



FIG. 3

- \* Lay out all pieces as in FIG. 1.
- \* Place square rod #1 into base. Secure with a knob at the bottom of the stand (FIG. 1)
- \* Slide "L" shaped piece #2 into the square rod #1 coming out of the base. Secure with a knob in the middle of the stand. (FIG. 1)
- \* Screw short, rod #3 onto rod #2 to make a longer "L" shaped piece. (FIG. 1)
- \* Slide rod #4 (the piece with a hook) onto "L" shaped piece. Secure with a knob on the top of the stand. (FIG. 1)
- \* Measure & adjust the light stand's top, horizontal piece until it is 10" long. (FIG. 2)
- \* Hang the **30W UV LED Blacklight** onto the hook by unfolding the hanging bracket on the light. The middle hole on the light's hanging bracket should be placed on the hook. Ensure the light is level with your work surface. (FIG. 3)
- \* Measure & adjust until the bottom of the **30W UV LED Blacklight** sits exactly **12" FROM YOUR WORK SURFACE**. (FIG. 3)
- \* Lastly, secure the cord with the 3 cord "clamps" found along the stand. (FIG. 3)



## SmallDogPrints Light Kit :

- \* 30W UV LED blacklight exposes film.
- \* Comes with a convenient ON/OFF switch & hanging bracket.
- \* Sits level at 12" from the work surface.
- \* Exposes SmallDogPrints film in 1 min.
- \* Comes w/a yellow "safe bulb" to see in dark.

**NOTE . . .** All lights & blacklights are **NOT** the same. There is no guarantee that other light sources will expose SmallDogPrints film.

**\*WARNING ...** keep SmallDogPrints light kit away from water to avoid electrical hazard.