

Installation Instructions for CenteraK Door Panel mount for Jeep JL Wrangler and JT Gladiator

Tools Needed for installation:

- Nylon pry tool
- Torx T-20 bit
- Phillips screwdriver

Use a Pry tool to remove the elastic band supported the door nets.



The elastic band must be slipped through the slot on in order to remove it.



Once the front and rear of the elastic band have been removed from the door panel, grab the door net down low and firmly pull up to remove the retaining rod from the door panel.



With the net now removed, use a T-20 bit to remove the 2 screws at the bottom of the door panel. These screws will not be re-used.



Insert the rearward side of the door panel mount into the hole that held the elastic band for the door net.



Now grab the Mount in the center and pull it away from the door while simultaneously pushing in on the panel near the front tab. The front tab will then be inserted into the hole where the door net elastic band was held in.



Once the front tab is in the hole slide the Mount forward.



Now install the two provided spacers in between the Mount and the door panel. These go where the screws were removed from earlier in the installation.



Now install the two provided screws.

