

Jeep JL/JLU Wrangler PACKOUT tailgate mount instructions



Tools needed for Installation:

- Nylon panel removal tool
 - 10mm wrench
 - 4mm hex key
 - 1/4" drill bit
 - 1/2" drill bit
 - Drill

Included parts:

- 1- mounting panel
- 1- filler plate
- 2- 70mm M6 bolts
- 2- 2 3/8" spacers
- 3- m6 nyloc nuts
- 6- 35mm m6 bolts
- 8- 3/4" spacers

1. Remove Jeep Trailrail Ready plastic panel from tailgate.



2. Orient Filler plate to line up with holes in tailgate. Note the orientation of all 6 holes.



3. Using 3- M6 35mm bolts, 3- 3/4" spacers, and 3- M6 nyloc nuts, bolt the filler plate to the mounting panel. The Centerak Logo will be on the right hand side of the panel.



- Using 3- M6 35mm bolts and 3- 3/4" spacers, loosely bolt the filler plate to the tailgate, starting with the center bolt, then the outer bolts. You will need to slip the 3/4" spacers behind the filler plate during this step.





5. Using a 1/4" drill bit, mark the location of the 2- lower holes on the mounting panel.



6. Remove the 3- bolts holding the filler plate to the tailgate. Using a 1/2" drill bit, drill out the factory tailgate panel where you marked it in the previous step. Then, install the 2- 2 3/8" spacers into the holes you just drilled.



7. Repeat step 4.

8. Install the last 2- 3/4" spacers on top of the 2 3/8" spacers, then install the M6 70mm bolts. Tighten all fasteners. Installation is complete.

