

## JEEP FRONT SOUNDSTAGE UPGRADE INSTALL GUIDE

JEEP WRANGLER (2014 - 2018 | JK)

Installation of our Front SoundStage Speaker Upgrade Kits is easy. Everything you need to install your kit is included in the box. Look for the tool kit underneath the foam protective insert. Follow the step-by-step guide provided in these instructions.

**Install Time:** 10 Minutes

**Tools Needed:**

- Panel puller (included)
- 7mm driver (included)

**SKU:** TL.JK.UDSS / TL.JK.UDSS.A



### STEP 1 - GRILLE REMOVAL

Using the enclosed panel puller tool, remove factory speaker grille. There will be two (2) clips holding it in place, one on each side.



## STEP 2 - SPEAKER REMOVAL

Remove the two screws holding the factory speaker in place using the enclosed driver. Then, lift the speaker up from the sub-dash assembly and unplug the speaker from the factory harness.



## STEP 3 - CONNECTING

Plug the Terra Acoustics tweeter/grille combo into the Terra Acoustics midrange driver.



## STEP 4 - CONNECT TO FACTORY

Plug the factory harness directly into the Terra Acoustics midrange driver.

**NOTE:** In Standard factory system cards DO NOT connect Jeep male plug to midrange connector. Connect factory male plug to WHITE plug on pigtail harness.



## STEP 5 - INSTALL IN DASH

Tuck the harness into the negative space below where the midrange sits, making sure the junction plug of the tweeter and midrange will be below the midrange.



## STEP 6 - GRILLE INSTALLATION

Using the factory screws, attach the Terra Acoustics midrange driver back to the dash. Taking careful note to insure tweeter wiring is contained within the perimeter of the reimagined grille, and NOT making contact with the area directly above the midrange, simply snap the grille back into place.



## STEP 7 - ENJOY YOUR MUSIC

That's it! Now start hearing your music again, for the very first time.

