



## MAXX AIR REPLACEMENT DOMES FOR ROOF MOUNTED POWER ATTIC VENTILATORS • ALL MODELS

This dome is designed with six points of attachment, and includes six (6) new dome brackets, twelve (12) #10 taper screws and three (3) U-clips.

If replacing an older dome with three brackets and a steel ring, these should all be removed, and replaced with the enclosed brackets (no ring is necessary). It is preferable to drill three (3) additional holes, equally spaced between the original holes.

If the motor bracket hole is too large for those brackets which also attach to the motor legs, use the three (3) U-clips included with the three (3) #10 taper screws involved.

It may also be necessary to remove the bird screen on the inside of the flange, breaking the joint, and to install it on the outside of the flange, resting on the new dome brackets. The joint should be replaced with wire, or a small bolt and nut with two (2) washers.

In order to maintain a 1/2" overlap between the bottom of the dome and the top of the flange, it may be necessary to cut the screen on either side of each bracket, and to bend it back in the bracket area. This will ensure that the screen does not hold the dome too high.

