



Installation Instructions for NXSRD Radiation Damper

1. Install the housing per the bath fan installation instructions. The opening edge of the damper sleeve should be flush or slightly above the ceiling surface.
2. Install the motor and blower assembly into the already installed housing, making the electrical connections per the bath fan instructions.
3. Install the radiation damper into the radiation damper sleeve per local code requirements by lining up the four (4) screw holes and inserting screws.
4. Install the grille by inserting the grille springs into the slots on the edge of the radiation damper.