



Portable Scratching Board User Guide

WAYS TO USE



Mount on the wall.



Place flat on the floor or on an angle.



Lean against the wall.



Tape to the wall or furniture.



SVD.PET is a registered trademark of Silicon Valley Devices LLC. @2019 Silicon Valley Devices LLC. Palo Alto CA 94306 www.SVD.PET Contact us: support@svd.pet

Scan the code to open the User Guide online





BOARD ASSEMBLY

Parts you need:

Please refer to the parts section.

Top board (#1); Bottom borad (#9); Woven sisal mat (#6) Connector for top board and bottom board (#10) Connector screws x 4 (#12)



1. Align the top and bottom boards. Attach the connector (#10). Secure with the connector screws (#12).



2. Insert the sisal mat (#6) on the top of the board. Press and smooth out the mat.

ATTACHING A TOY

Choose a toy to attached to the board.



Double-sided tapes x 3 (#11)

1. Tape to the wall or furniture

Parts you need:

Please refer to the parts section.



- 1. Put the 3 double-sided tape on the back of the board.
- 2. Tape the board to the desired place.

2. Place on the floor

Parts you need: Please refer to the parts section. Anti-slip pads x 4 (#14)



1. Applied the 4 anti-slip pads to the back four corners of the board.



2. Place the board flat on the floor; or, place the board on the floor with an angle by opening-up the floor stand.

3. Mount on the wall with screws

Parts you need:

Please refer to the parts section.

Short screws and anchors x2 (screw lenght: 2.5cm Long) (#5)



1. Use the yellow ribbon to help you to grab the edge of the sisal mat, then peel the mat off the board.



2. Place the board at the desired location. Use a pen to mark the mounting holes.



3. Drill holes in the center of the pen markings with a 15/64 (6mm) drill bit.



4. Insert the drywall anchors into the drilled holes.



 Line up the mounting holes on the board with the anchors. Insert and fasten the short screws(#5) into the anchors.



6. Place the mat back on the board. Insert the spring toy or the hanging toy.

4. Lean against the wall with screws

Parts you need:

Please refer to the parts section.

Long screws and anchors x2 (screw lenght: 4cm Long) (#4)



 Lean the board on the wall at the desired location. Place the wall angle support part(#13) 16.5 inches (42cm) from the floor. Use a pen to mark the mounting holes.



2. Drill holes in the center of the pen markings with a 15/64 (6mm) drill bit Insert the drywall anchors in the drilled holes.



3. Use the yellow ribbon to help you to grab the edge of the sisal mat, then peel the mat off the board.



4. Insert the wall angle support on the back of the board.



 Line up the mounting holes on the board with the anchors. Insert and fasten the long screws(#4) into the anchors.



6. Place the mat back on the board. Insert the spring toy or the hanging toy.