

## Set up instruction of plastic parts

***(Note: Please refer MID XRX/R Instruction for set up)***

1. Assemble the decorative board & cover: assemble the decorative board & cover with screw ST4.2\*16 (pic. 1)



pic. 1

2. Install the bumper: install the bumper with nut M6\*12 on frame (pic. 2)



pic. 2

3. Install decorative board and cover assemble: install decorative board and cover assemble with nut M6\*16 on frame (pic. 3)

4. Installation completed (pic. 4)



pic. 3



pic. 4